



# 107-16-VP-LS

Non-Recessed Vandal Proof Drinking Fountain  
With Vandal Proof Bottle Filler and ADA Compliant Cane Apron



Fountain bowl, cane apron and cover plate shown in standard #4 stainless steel satin finish with a "Soft Touch" button valve, bubbler and vandal proof bottle filler in mirror finish

Illustration Only

Dimensions in drawing subject to options selected.

## Features

- 16" diameter, 16 ga. fountain bowl
- No plastic parts
- 100% made in the USA
- ADA Compliant
- Manufactured with lead-free materials
- Integral drain in bowl for ease of cleaning
- 1/4" steel support arms and wall bracket capable of supporting 500 lbs.
- Cover plate and access panel to match bowl finish or choose from unlimited powder coat colors
- Options include sensor activation, bottle counter, finishes, bubbler valves, and more...

## Recommended Add-ons


### Chiller

Equip your fountain with a Filtrine point-of-use or remote chiller to cool your drinking water. We can help you select the most economical chiller model to fit your demand.


### Purifier

Ensure that your drinking water is of the highest quality by adding a Filtrine Taste Master® purifier cabinet underneath the fountain or a remote purification system serving all fountains in the building.


## Top View



## Side View



## Front View



For options, finishes and more see page 2



# Vandal Proof Non-Recessed Fountain Options

[S] - Standard  
[♿] - ADA compliant

## Standard Vandal Proof Bottle Filler


### Features:

- Mounted 10½" above lowest fountain bowl
- Comes standard with bottom security panel assembled with tamper proof screws and "Soft Touch" button valve
- Supply plumbing and mounting tongue for filler provided by Filtrine



"Soft Touch" Button Valve with Recessed Set Screw


## Bubbler Control Options (Check One)



## Bottle Filler Options

### "Hands Free" Sensor Activated

- 4x -AA lithium batteries (included)
- Runs approximately 400,000 cycles
- Features automatic shutoff (30 sec)
- Includes 6" access panel below fountain for sensor controls (see below)



### Bottle Rest\*\*

- Located above lowest fountain for reduced splash and one handed operation
- \*\*Recommended with sensor activation

## Standard Security Panel and Vandal Proof Bubbler

"Soft Touch" Button and Projector Bubbler with Recessed Set Screws

16 ga. Plate Secured with Tamper-Resistant Screws for Added Security



4x Tamper-Resistant Screws

## Standard 21" High Cover Plate

- 16 gauge metal construction
- Material and finish for cover plate can be selected below


Cover Plate Friction Fit on Mounting Plate



## Access Panel Options

### 6" Standard Height

### Other Height \_\_\_\_\_ in



## Fountain Finish (Check One)

- Satin Stainless [S]    Mirrored Stainless    Satin Bronze    Mirrored Bronze    Statuary Bronze    Oil-Rubbed Bronze

## Cover Plate Finish (Check One)

- Satin Stainless [S]    Mirrored Stainless    Powder Coat \_\_\_\_\_    Satin Bronze    Mirrored Bronze    Statuary Bronze    Oil-Rubbed Bronze

## Stainless




Satin Stainless Steel [S]



Mirrored Stainless Steel

## Bronze



Satin Bronze



Mirrored Bronze




Oil Rubbed Bronze



Statuary Bronze



## Mounting Plate Details (Front)



Approximate Rough-In Dimensions (hatched, left)

Model	Height	Width
Standard Plate	26 1/2"	8"


Approximate Access Panel Rough-In Dimensions (outlined, left)

Model	Height	Width
Standard Panel	5 1/2" *	14 1/2"

\*If height specified, rough-in height will be 1/2" less than specified height


All views shown are for typical installation of 107-16-VP-LS. Views, dimensions and diagrams may change for specific installation requirements.

## Exploded On-Wall Installation View 107-16-VP-LS with Access Panel




## 1/4" Steel Mounting Plate Should Be Mounted on Wall Surface.

### On-wall Mounting Detail With Cover Plate




## Typical Assembly Instructions (Always Install Per Local Code)

- Cut rough opening as shown above and install blocking or fixture carrier as required to support the assembly.
- If optional access panel was ordered cut a separate rough opening (table, top right) extending below the fountain mounting plate.
- Run drain piping to center of openings on mounting plate and install drain trap in wall per local code.
- Run supply water line with service valve, if necessary.
- Attach piping assembly provided by Filtrine to the back side of the mounting plate.
- Fasten mounting plate over rough opening with 5/16" countersunk lag bolts with bottom of plate 26" above the floor to meet ADA fountain height requirement of 34 1/4" to the bubbler spout.
- Install cover plate over the mounting plate.
- Slide each fountain and vandal proof bottle filler arm over the horizontal tongues protruding from the mounting plate and fasten arms with set screws pushing slightly against the cover plate or finished wall.
- Connect drain line to slip coupling and connect supply water connection.
- Install security panels under fountain arm and vandal proof bottle filler with tamper resistant screws.
- If your model includes the access panel, measure, mark and install the included "L" brackets with #8-32 screws and align panel to cover plate with alignment pins.



## Access Panel Mounting Brackets Installation Details



## Typical Drain Plumbing Detail (In-Wall Plumbing Provided By Others, Install Per Local Code)

