




107-16-HL

Non-Recessed, Vandal Proof, High/Low Drinking Fountain






Model 107-16-HL Drinking Water Installation Drawing



Exploded On-Wall Installation View 107-16-HL with Access Panel




Typical Drain Plumbing Detail

- 1. Cut rough opening as shown above and install blocking or fixture carrier as required to support the assembly.
- 2. If optional access panel was ordered cut a separate rough opening (table, top right) extending below the fountain mounting plate.
- 3. Run drain pipe to center of openings on mounting plate and install drain trap in wall per local code.
- 4. Run supply water with service valve, if necessary.

Access Panel Mounting Brackets


Filtrine

- 5. If optional bottle filler is included with order, attach piping assembly provided by Filtrine to the back side of the mounting plate with two screws and rubber gasket for standard bottle filler and flare connection for vandal proof bottle filler.
- 6. Fasten mounting plate over rough opening with 5/16 "countersunk lag bolts with bottom of plate 27" above the



- 7. Install cover plate over the mounting plate for on-wall installations.
- 8. Slide each fountain and vandal proof bottle filler arm (if ordered over the horizontal tongues protruding from the mounting plate and fasten arms with set screws pushing slightly against the cover plate or finished wall.
- 9. Connect drain line to slip coupling and connect water connection.
- 10. If your model includes the access panel, measure, mark and install the included "L" brackets with #8-32 screws and align panel to cover plate with alignment pins.

(In-Wall Plumbing Provided By Others, Install Per Local Code)




Mounting Plate Rough-In Dimensions (hatched, left)

MODEL	HEIGHT	WIDTH
Standard Plate	151/2"	8"
Bottle Filler Station	20 ¹ /2"	8"

Access Panel Rough-In Dimensions (outlined, left)			
Model	Height	Width	
Standard Plate	5 ¹ /2"	301/2"	

Note: All views shown are for typical installation of 107-16-HL. Views, dimensions, and diagrams may change for specific installation requirements.



In-wall Mounting Detail Without Cover Plate

