

# FCC-107-16-HL

Non-Recessed, High/Low Drinking Fountain with In-Wall Chiller and Taste Master® Purifier



Fountain bowl, cover plate and chiller cabinet shown in standard stainless steel satin finish with "Soft Touch" button valves, bubblers and optional integral "Push Back" lever bottle filler in mirror finish

Dimensions in drawing subject to options selected.

#### **Features**

- [2] 16" diameter, 16 ga. fountain bowls
- No plastic parts
- 100% made in the USA
- Manufactured with lead-free materials
- · Integral drain in bowl for ease of cleaning
- ½" steel support arm and wall bracket capable of supporting 500 lbs.
- Matching cover plate and cabinet finishes including unlimited powder coat colors
- Options include vandal proof bubblers, bottle fillers, bottle counters, finishes, bubbler valves, and more...

## FCC-107-16-HL Models Include:

## **Chiller: Model 56A**

- Water in: 1/4" FPT
- Cooling Capacity: 6 GPH @ 50°F [10°C]\*
- · Storage: 2 gal, insulated stainless steel tank
- Refrigerant: HFO R513A "Ozone Safe -Low GWP"
- Electrical: 115/60/1 or specify \_\_\_\_\_
- \*Higher capacity chillers are available consult factory for correct model #s.

## Purifier: Taste Master® TMS1-0.5

- Construction: Stainless steel housing
- Element: Carbon block removes particulates, cysts, chlorine, organic odors and tastes. Exclusive seal design negates bypassing and leaking.

**Top View** Chiller Select Low Fountain Location ☐ Left [S] □ Right Side View Rough-in Depth Location 81/4" Ø 16' Supply Bowl Depth See Options Page for **Bubbler** Types **Front View** 24 1/16" Supply Height 38//" 40" or 45" With Optional Bottle Filler 32// See 24' **Options** Page for **Bottle Filler Types** For options, finishes 30' and more see page 2





### [S] - Standard iltrine **Filtrine Drinking Water Non-Recessed Fountain Options** - ADA compliant **Bubbler Controls** (Check One) ■ Optional Vandal Proof Bottle Filler (Choose only one optional filler) □"Soft Touch" Valve □Sensor Activation\* ☐Bottle Rest - Located above lowest bowl for reduced splash and one handed operation ☐Bottle Counter - Digital display of approx. number of bottles saved through fountain usage Note: Only available with sensor activation • Mounted 10" above lowest fountain bowl. Comes standard with bottom security panel assembled with tamper proof screws. Requires larger cover plate and mounting plate. □"Push Button' ☐ "Soft Touch' "Easy Touch" Supply plumbing and mounting tongue for filler **Lever Valve** Button Valve [S] Valve provided by Filtrine. \*Not available with sensor activated bubbler on same bowl. ☐ Optional Fountain Sensor Activated Bubbler\* (Choose only one ☐ Optional Integral "Push Back" Lever Bottle Filler optional filler) • Mounted 10" above lowest fountain bowl. • Requires larger cover and mounting plates. • Easy-to-use stainless steel "push back" lever. "Hands Free" • Supply plumbing and mounting fitting for Sensor filler provided by Filtrine. Activator Uses 4x -AA lithium batteries (included), runs □ Optional Security Panel approximately 400,000 activation cycles. 16 ga. Plate Features automatic shutoff Secured with (30 sec). Tamper-Resistant Helps prevent vandalism and Screws for Added water waste. Security -\*Not available with sensor activated bottle filler on same 4x-Tamper bowl. Resistant Screws **Fountain Finish** □ Satin Stainless [S] □ Mirrored Stainless □ Satin Bronze □ Mirrored Bronze □ Statuary Bronze □ Oil-Rubbed Bronze Optional Cover Plate Finish (Check One) □ Satin Stainless [S] □ Mirrored Stainless □ Powder Coat □ Satin Bronze □ Mirrored Bronze □ Statuary Bronze □ Oil-Rubbed Bronze Stainless **Bronze**









**Statuary Bronze** 

Filtrine Mfg. Co. • 15 Kit St. Keene, NH 03431 USA 800-930-3367 • 603-352-5500 • FAX 603-352-0330 www.filtrine.com • drinkingwater@filtrine.com








FCC-107-16-HL Options Page [EB] 01/30/2019



# **Model FCC-107-16-HL Drinking Water Installation Drawing**



#### Approximate Rough-In Dimensions (hatched, left)

Model	Height	Width
Standard Plate	15½"	8"
Bottle Filler Plate	20½"	8"


# Approximate Chiller Cabinet Rough-In Dimensions (outlined, left)

Model	Height	Width
Standard Cabine	t* 23"	30½"

\*Wall opening should be a minimum of 10" deep to allow room for chiller cabinet

All views shown are for typical installation of FCC-107-16-HL. Views, dimensions and diagrams may change for specific installation requirements.


## FCC-107-16-HL Exploded and Dimensions Installation Views



#### Typical Assembly Instructions (Always Install Per Local Code)

- 1. Cut fountain rough openings per install requirements (rough opening example shown above) and install blocking or fixture carriers as required to support the drinking fountain mounting plate and chiller cabinet in a minimum 10" deep wall.
- 2. Cut a separate rough opening extending below the fountain mounting plate, 23" high x 30½" wide maximum rough in opening dimensions.
- 3. Run drain piping to center of openings on mounting plate (dimensioned above), and install drain trap(s) in wall per local code.
- 4. Run supply water line to mounted Taste Master® filter housing.
- 5. If optional bottle filler is included with order, attach piping assembly provided by Filtrine to the back side of the mounting plate with two screws and rubber gasket for standard bottle filler and flare connection for vandal proof bottle filler.
- 6. Fasten mounting plate to mounting surface over rough opening with  $\frac{5}{16}$ " countersunk lag bolts with bottom of plate 26" above the floor to meet ADA fountain height requirement of  $34\frac{1}{4}$ " to the bubbler spout.
- 7. Install chiller cabinet in rough opening below the mounting plate using  $\frac{3}{6}$ " holes in the side flange of the cabinet. Chiller cabinet should be located approx.  $\frac{1}{2}$ " below and centered with the mounting plate above.
- 8. Install cover plate over mounting plate, and slide each fountain and vandal proof bottle filler arm (if ordered) over the horizontal tongues protruding from the mounting plate and fasten arms with set screws pushing slightly against the cover plate.
- 9. Connect drain line to slip coupling at each fountain and connect supply line to filter housing.

LEAD



Filtrine Mfg. Co. • 15 Kit St. Keene, NH 03431 USA 800-930-3367 • 603 352-5500 • FAX (603) 352-0330 www.filtrine.com • drinkingwater@filtrine.com



FCC-107-16-HL Installation Drawing [EB] REVISED 01/30/2019